





Kurzanleitung



1




NOMIA SERIE

12V100Ah | 12V160Ah | 12V210Ah
12V340Ah


A

Verbindung mit einem normalen Relais


1





2




3









4



5





Anleitung downloaden unter:
www.super-b-service.de

Version 1.2



Europalaan 202
 7559 SC Hengelo(Ov)
 The Netherlands
 T+31(0)88 00 76 000

Contact us:
info@super-b.com

Visit our website
www.super-b.com



www.super-b-service.de